

experiment results. **Table 3** shows play, well, rock sample depth and reservoir temperature for tested samples.

**Table 3. ULR rock sample sources and depths. Reprinted with permission from Alvarez and Schechter (2016c)**

| ULR                                       | Well | Sample | Depth (ft) | ULR                                     | Well | Sample | Depth (ft) |
|---|------|--------|------------|---|------|--------|------------|
| Bakken Reservoir Temperature (220 °F)     | Bk-1 | 1      | 9620       | Barnett Reservoir Temperature (165 °F)  | Br-1 | 1      | 6060       |
|   |      | 2      | 9630       |   |      | 2      | 8018       |
|   |      | 3      | 9635       |   |      | 3      | 8582       |
|   |      | 4      | 9640       |   |      | 4      | 8700       |
|   | Bk-2 | 1      | 10765      |   | Br-2 | 1      | 6896       |
|   |      | 2      | 10770      |   |      | 2      | 7017       |
|   |      | 3      | 10775      |   |      | 3      | 7030       |
|   |      | 4      | 10780      |   |      | 4      | 7616       |
| Eagle Ford Reservoir Temperature (218 °F) | EF-1 | 1      | 13030      | Wolfcamp Reservoir Temperature (165 °F) | W-1  | 1      | 7790       |
|   |      | 2      | 13040      |   |      | 2      | 7830       |
|   |      | 3      | 13125      |   |      | 3      | 7835       |
|   |      | 4      | 13135      |   |      | 4      | 7880       |
|   | EF-2 | 1      | 14185      |   |      | 5      | 7910       |
|   |      | 2      | 14220      |   | W-2  | 1      | 8335       |
|   |      | 3      | 14245      |   |      | 2      | 8370       |
|   |      | 4      | 14250      |   |      | 3      | 8385       |
|   |      |        |            |   |      | 4      | 8425       |

### *X-ray diffraction and total organic carbon analysis*

X-ray diffraction and total organic carbon analysis experiments are conducted to evaluate the nature of the rocks analyzed as well as the lithological variability of ULR with depth. Determine the mineralogical composition of ULR pay zones is critical to select completion fluids that improve water imbibition and favor oil recovering when fracturing the formation (Alvarez and Schechter 2016a). XRD and TOC results for Bakken and Eagle Ford are in **Table 4**.

XRD results for Bakken wells show different lithologies from the two wells analyzed. Well Bk-1 is more siliceous with higher content of quartz whereas well Bk-2